



## Deployment Check with XBEE Instructions and Check out Sheet

---

1. Make sure computer is plugged into a power source and has sleep turned off.
2. Plug XStick into USB
3. Open Tera Term and make sure it is connected to the right serial port for the XStick
  - a. Setup > Serial Port > Port
4. Setup a Logfile
  - a. File > Log
  - b. Filename should be float number, date, and deployment.  
Ex. 6012Jan2015Deployment
  - c. Make sure Timestamp, Append, and Plain Text are checked
5. To check and make sure you are talking to the XStick type “+++”. You should get an “OK” returned.  
If not check connections and com port and try again.
6. Ready to start test